



LUBRICATION CHART CLIMBER 10 AWD 22/27

	ТҮРЕ	QUANTITY	
ENGINE OIL	SAE30	2 LITRES	Change oil and replace the filter within the first 20 hours, then after each 100 hours.
FRONT AND REAR HYDRAULIC AXLES	5W50	5 LITRES	First oil change after 50 hours, then after each 200 hours or once a year.
LUBRICATION POINTS	GREASE (EA3)		Lubricate with grease each 40 hours the forward levers, the lift cutter deck parallelogram, the 2 point coupling pin of the cutter deck and the ball joints (follow the lubrication scheme).