



HOW-TO: LAWN MOWER

BLADE MAINTENANCE TIPS

Lawn mower blade maintenance is crucial for keeping your lawn mower in good condition and ensuring a clean and even cut on your lawn. Here are some tips to help you maintain your lawn mower blades:

STEP 1 - CLEAN THE BLADES REGULARLY

After each use, remove any grass or debris from the blades using a brush or cloth. This will help prevent rust and keep the blades sharp.

STEP 2 - SHARPEN THE BLADES

Dull blades can damage your lawn and cause an uneven cut. You can sharpen the blades yourself using a sharpening stone or take them to a professional to have them sharpened.

STEP 3 - CHECK FOR DAMAGE

Regularly inspect the blades for cracks, bends, or other signs of damage. If the blades are damaged, replace them immediately.

STEP 4 - BALANCE THE BLADES

balanced blades can cause vibrations and damage to your lawn mower. To balance the blades, you can use a blade balancer or take them to a professional.

STEP 5 - CHANGE THE BLADES

Over time, blades can become worn out and need to be replaced. It's recommended to replace the blades at least once a year, or more often if you mow frequently or have a large lawn.

By following these tips, you can keep your blades in good condition and ensure a healthy and beautiful lawn! Contact our dedicated service team if you need help or parts.

QUALITY BRANDS, EXCEPTIONAL SERVICE.



parkland.co.nz